EN WO806 LED outdoor wall lighting Ragusa



Thank you for purchasing our Ragusa outdoor wall lighting equipment. The luminaire has a built-in switch that allows you to preset the chromaticity temperature (light) from warm to cool white. The fixture is suitable for installation on outdoor walls as well as indoors. Before installing and using the device, read these instructions carefully and pay attention to the safety warnings and instructions. This will ensure not only the protection of persons, but also the long-term viability of the equipment. Do not repair or modify the equipment, installation must only be carried out by a qualified technician. The operating temperature of the equipment is between -20°C and 50°C.

Technical parameters

	WO806
Power	220-240V AC
Consumption	7W
Luminous flux	450lm
Chromaticity	3000K/4000K/6000K
Colour rendering index Ra	>80
Degree of protection	IP 54
Dimensions	150 x 160 x 60 mm

Installation

Disconnect the power supply before installation!

- 1. Unscrew the side screws on the bottom of the device.
- 2. Remove the bottom cover.
- 3. Pull the power cord through the bottom cover.
- 4. Insert dowels into the pre-drilled holes and screw the cover into the selected location.
- 5. Unscrew the cable coupler.
- Connect the supply cable to the cable coupler, making sure the connection is correct. (Refer to the green ring on the coupler for wiring markings.)
 Tighten the coupler when finished.
- 7. Insert the cable coupler into the body of the luminaire.
- 8. Attach the top of the luminaire to the bottom cover and screw the side screws in place.

Safety warning

- Installation may only be carried out by a qualified worker.
- Do not cover the luminaire with anything or hang anything on it.
- Do not repair or modify the equipment in any way.

* Chromaticity

switch

The light source of this luminaire is non-replaceable, at the end of its service life the entire luminaire must be replaced and disposed of in a designated place. This product contains a light source that for design reasons cannot be removed for verification and therefore the entire product is considered a light source. The power cord cannot be replaced if damaged, the unit must no longer be used..



^{*} Use the chromaticity switch to select the desired light temperature (3000K/4000K/6000K). The switch slider can be found on the underside of the white cover of the luminaire.