

Dear customer, thank you for purchasing our handheld flashlight. Please read the following instructions before using it for the first time. The power bank function is only an additional function, it is used to partially charge your mobile phone and cannot be compared with dedicated power banks.

TECHNICAL PARAMETERS

Luminous flux	800 lm
LED	P50 (10 W max.)
Illumination time	max. 10 hours, min. 4 hours
Charging time	approx. 10 hours.
Dimensions of the flashlight	115 x 115 x 270 mm
Coverage	IP44
Accumulator	3.7 V 4500 mAh lead acid

PACKAGING CONTENT

1x flashlight, 1x charging cable, 1x instruction manual

CHARGE

Fully charge the battery before using the flashlight for the first time. Connect the flashlight with the supplied Micro-USB cable to the 5V charging adapter (not included). Plug the charger into a 230 V socket. At this point, the charging process will begin, which is indicated by three blue flashing LEDs. As soon as all LEDs start to light up continuously, the battery is fully charged. The battery cannot be removed from the device. Press the button next to the LEDs to display the battery charge status.

LIGHTING MODES

Number of presses buttons	1	2	3	4
Lighting mode	100%	50%	30%	Flicker

Notice

1. The surface of the flashlight heats up slightly during use. Therefore, take extra care when handling the flashlight during and immediately after use.
2. If you do not use the flashlight for a long time, plug the battery into the charger for 10 minutes every three months.
3. Disconnect all cables for long-term storage.
4. Never look directly into a lit torch. Your eyesight could be damaged.
5. Do not disassemble or modify the equipment in any way.
6. The flashlight can be screwed to the stand (not included), the attachment hole can be found on the bottom side.

The 24-month warranty does not apply to wear and tear caused by normal use, according to Section 619(2) of the Civil Code, so the declining battery capacity is not a reason for accepting a claim for these goods.

